

# 1 - How to choose the default card to Arduino MEGA

You have to edit the file:

```
/generators/arduino/blocklyduino.js
```

and modify the *line 93*:

```
profile["default"] = profile["arduino_uno"];
```

changing **arduino\_uno** by **arduino\_mega**.

## 2 - How to choose the default blocks categories

You have to modify the file `/utils/blocklyDuino.js` at *line 479*.

You can find the list of blocks categories at `LoadIds =` line:

```
// set the default toolbox if none in session
if (loadIds === undefined || loadIds === "") {
loadIds =
"CAT_LOGIC,CAT_LOOPS,CAT_VARIABLES,CAT_FUNCTIONS,CAT_MATH,CAT_TEXT,CAT_ARDUI
NO,CAT_TECHNOZONE";
window.sessionStorage.toolboxids = loadIds;
}
```

You can find the categories list name to write at line **LoadIds** in the file `index.html` starting *line 246* in "toolboxes definitions" .

From:

<http://www.technologiescollege.fr/wiki/> - LibrEduc

Permanent link:

[http://www.technologiescollege.fr/wiki/doku.php?id=en:blockly\\_rduino:tweak](http://www.technologiescollege.fr/wiki/doku.php?id=en:blockly_rduino:tweak)

Last update: **2021/02/28 10:07**

